

How to Use Your Bear-Resistant Trash Cart

Using your bear-resistant trash cart is as easy as **1-2-3!**



- 1 Reach** under the apron and find the slider located on the left.
- 2 Slide** the slider from left to right to release the lock.
- 3 Lift** the lid.

Thanks for doing your part to keep Whitefish clean and to protect our wildlife! Questions? Call 406.863.2456.

RepublicServices.com/Montana